





INSULATION & PACKAGING DISTRIBUTORS CC

ALUBUBBLE AND ALUCUSHION INDUSTRIAL FIXING INSTRUCTIONS

Fix PVC coated straining wire by passing it through 5mm holes drilled in the top faces of the apex/top purlin and the eaves/bottom purlin at 383mm centres. The wire to pass over the intermediate purlins. The first straining wire to be fixed 50mm away from gable end. Evenly tension all wire ensuring that cut ends face downwards.



Roll Alububble down the slope of the roof and cut to length with an additional 200mm of material to use as a grip for tensioning the material. Fix Alububble over the straining wires and ensure that it is laid square to the building. Attach Alububble to the eaves purlin using good quality double sided adhesive tape of either 24mm or 48mm width. Firmly grip the top end of the material and pull to tension the Alububble and attach to the apex purlin again using double sided tape.



All subsequent sheets of Alububble to be fixed as above with a minimum of 100mm overlap over the previous sheet. To achieve the best visual effect, install Alububble starting from the end of the building from where one wants to see the neatest finish. Straining wires must be positioned at the centre of the overlaps i.e. not more than 50mm from the edges of the sheet. Lay the roof sheeting as soon as possible after the fitting of Alububble.

This products inherent fire retardant qualities makes it more suitable for use in a vertical application. Double sided tape should be used to seal the overlap.

STRAINING WIRE

1.6mm Gauge PVC Coated Straining Wire
Roll Lengths: 625m & 1250m

1.6mm Gauge Galvanised Straining Wire
Roll lengths: 750m & 1250m

ADHESIVE TAPES:

24mm Double Sided Tape
36mm Double Sided Tape
48mm Double Sided Tape
48mm Aluminium Tape

